



PARTS BREAKDOWN

AIR COMPRESSOR

MODEL:AC072



BEPOWEREQUIPMENT


.COM



PARTS BREAKDOWN AIR COMPRESSOR

MODEL:AC072

PUMP AND MOTOR ASSEMBLY




REF #	DESCRIPTION	QTY	BE PART #
7	Piston Ring	2	42.011.027
8	Piston	2	
9	Inner Hexagon Screws	2	
10	Cylinder	2	
13	Air Filter Assembly	1	42.011.001
18	Discharge Elbow	3	42.011.028
27	Shock Pad	4	42.011.029
28	Cable Retaining Clip	2	42.011.030
46	Waterproof Nut	1	42.011.032
47	Cross Joing Screw M5*14	2	
48	Connecting Box	1	
49	Capacitor	1	42.011.034
50	Wiring Cap	2	85.506.031
Not Shown	Black Plastic Pump Cover	2	42.011.033
1-36	Motor Pump Assembly Kit	1	42.011.036



PARTS BREAKDOWN AIR COMPRESSOR


MODEL:AC072

PRESSURE SWITCH ASSEMBLY



REF NO.	DESCRIPTION	QTY	PART NO.
38	Safety Relief Valve	1	42.010.150
40	Pressure Switch	1	42.011.009
42	Regulator	1	42.011.006
43	Quick Coupler	1	42.011.005
44	Pressure Gauge (50mm)	1	42.011.007
45	Pressure Gauge (40mm)	1	42.011.008

TANK ASSEMBLY



REF NO.	DESCRIPTION	QTY	PART NO.
52	Check Valve	1	42.001.025
53	Release Pipe	1	42.011.004
54	Steel Wire Hose M14	2	42.011.031
56	Washer Foot	4	42.011.003
59	Tank Drain Valve	1	42.011.002

BE

POWER EQUIPMENT

If you need technical assistance call:

1-866-850-6662

(8:00am - 4:30pm PST, Mon - Fri)