## EG6500

- Economical, portable power with traditional Honda durability and performance
- . 6,500 watts maximum AC output
- Home stand-by and Commercial usage (for non-GFCI applications)
- Suitable for rental applications



AND THE CONTRACT OF THE CONTRA		AND DESCRIPTION OF THE PROPERTY OF THE PROPERT	
GENERATOR TYPE	BRUSH TYPE	TRANSPORT WHEELS	OPT. (P/N 06710-Z22-A40ZA)
MAXIMUM AC OUTPUT (WATTS)	6500	LIFTING HOOK	OPT. (P/N 06810-Z22-A30ZA)
VAC VOLTAGE AVAILABLE	120 / 240	BATTERY	N/A
MAXIMUM CONTINUOUS AC OUTPUT (WATTS)	5500	APPROXIMATE RUNNING TIME / TANKFUL (HRS.)	7.1** / 10.0****
MAX. RATED AC AMPERAGE @ 120 V / 240 V	45.8 / 22.9	RATED FUEL CONSUMPTION (LITRES / HOUR)	3.38**
GROUND FAULT CIRCUIT INTERRUPTER (GFCI)		NOISE LEVEL (DBA) (1.5 METRES TO 7 METRES)	74**
FREQUENCY (HERTZ)	60	LENGTH (WITHOUT HANDLES AND WHEELS)	681 mm (26.8 in.)
AUTOMATIC VOLTAGE REGULATOR	STD. DIGITAL (DAVR)	LENGTH (WITH HANDLES AND WHEELS)	-
DC OUTPUT (VOLTS / AMPS)	-		
ENGINE TYPE	Honda GX390T2, OHV, 4-STROKE, AIR- COOLED	WIDTH (WITHOUT HANDLES AND WHEELS)	530 mm (20.9 in.)
DISPLACEMENT	389 cc	WIDTH (WITH HANDLES AND WHEELS)	=
STARTING SYSTEM	MANUAL RECOIL	HEIGHT (WITHOUT LIFT-HOOK)	571 mm (22.5 in.)
LOW LEVEL OIL ALERT™ SYSTEM	STD.		
AUTO THROTTLE	21-	HEIGHT (WITH LIFT-HOOK)	-1
REMOTE START CAPABILITY	МО	DRY WEIGHT	80 kg (176.4 lb)
REMOTE START KIT PART NUMBER INFO		COLD CLIMATE TECHNOLOGY	STD.
FUEL TANK CAPACITY (LITRES)	24	COMMON DUPLEX RECEPTACLE SPECIFICATIONS	40 amps / 120 VAC continuous is available as combined total from these two AC receptacles. Maximum of 20 amps available from each single receptacle.
		DC RECEPTACLE SPECIFICATIONS	2
		DC CHARGING CABLE	N/A
		HIGH CAPACITY 120/240 AC TWIST LOCK RECEPTACLE SPECS	This receptacle will supply 30 amps at 120 VAC continuously. This receptacle will supply 22.9 amp 240 VAC continuously and 45.8 amps at 120 VAC.

Models and/or colours may not be exactly as shown. Errors and omissions excepted. Specifications are subject to change without notice.

See your Honda Power Equipment dealer for details.

For optimum performance and safety, please read your owner's manual before operating your Honda product. Always wear the appropriate safety gear when operating your Honda.

@/TM — Trademarks of Honda Canada Inc. or used under licence from Honda Motor Co., Ltd. or third parties.