



PARTS BREAKDOWN INVERTER GENERATOR

MODEL:BE3500IP



BEPOWEREQUIPMENT


.COM



PARTS BREAKDOWN INVERTER GENERATOR


MODEL:BE3500IP

CRANK CASE / GEAR ASSEMBLY



REF #	DESCRIPTION	QTY	BE PART #
2	DRAIN PLUG WASHER	2	85.571.713
3	DRAIN PLUG BOLT	2	
5	BEARING	1	85.571.714
6	OIL-SEAL	1	85.571.715
11	SENSOR, ENGINE OIL	1	85.571.716

CRANK CASE COVER




REF #	DESCRIPTION	QTY	BE PART #
2	OIL DIPSTICK	1	85.571.717
5	GASKET, CRANKCASE	1	85.571.718



PARTS BREAKDOWN INVERTER GENERATOR

MODEL:BE3500IP

CYLINDER HEAD ASSEMBLY / SPARK PLUG




REF #	DESCRIPTION	QTY	BE PART #
1	VALVER COVER BOLT	4	85.571.719
2	VALVE COVER	1	
3	VALVE COVER GASKET	1	
4	SPARK PLUG	1	85.571.720
7	BREATHER TUBE	1	85.571.721
8	CYLINDER HEAD	1	85.571.722
9	EXHAUST STUD	2	85.571.723
10	INTAKE STUD	2	85.571.724
11	CYLINDER HEAD GASKET	1	85.571.725
3	VALVE COVER GASKET	1	
6	OIL - SEAL	1	
5	HEAT SHIELD COVER	1	



PARTS BREAKDOWN INVERTER GENERATOR


MODEL:BE3500IP

CRANKSHAFT CONNECTING ROD



REF #	DESCRIPTION	QTY	BE PART #
1	CRANKSHAFT ASSEMBLY	1	85.571.726

CRANKSHAFT ROD & RING SET




REF #	DESCRIPTION	QTY	BE PART #
1	PISTON RING SET	1	85.571.727
2	CONNECTING ROD	1	85.571.728
3	PISTON	1	85.571.729
4	PISTON PIN	1	
5	PISTON PIN CLIP	2	
1	PISTON RING SET	1	



PARTS BREAKDOWN INVERTER GENERATOR

MODEL:BE3500IP

CAMSHAFT ROD & RING SET




REF #	DESCRIPTION	QTY	BE PART #
1	CAMSHAFT ASSEMBLY	1	85.571.730
7	TAPPET VALVE	2	
2	VALVE	1	85.571.731
3	SEAL GUIDE	1	
4	VALVE SPRING	2	
5	VALVE SPRING SEAT	2	
6	VALVE LOCK CLAMP	4	
9	PLATE SUBASSEMBLY, LIFTER STOPPER	1	
10	VALVE ADJUSTING BOLT	2	85.571.732
11	ROCKER VALVE	2	
12	VALVE ADJUSTING NUT	2	
13	VALVE LOCK NUT	2	
8	LIFTER VALVE	2	85.571.733
9	PLATE SUBASSEMBLY, LIFTER STOPPER	1	
10	VALVE ADJUSTING BOLT	2	
11	ROCKER VALVE	2	
12	VALVE ADJUSTING NUT	2	
13	VALVE LOCK NUT	2	



PARTS BREAKDOWN INVERTER GENERATOR


MODEL:BE3500IP

STARTER RECOIL



REF #	DESCRIPTION	QTY	BE PART #
1	STARTER, RECOIL	1	85.571.700
3	STARTING ROPE GUIDE	1	
4	CABLE HANDLE OUTER SLEEVE	1	
5	BOLT	3	85.571.734
6	STARTER PULLEY	1	
7	STARTER CLIP SEAT	1	

CARBURETOR ASSEMBLY




REF #	DESCRIPTION	QTY	BE PART #
1	CARBURETOR INSULATOR GASKET	1	85.571.701
2	CARBURETOR INSULATOR PLATE	1	
3	CARBURETOR GASKET	1	
4	CARBURETOR ASSEMBLY	1	
5	CLAMP	2	
6	FUEL TUBE	1	
7	CAP	1	
8	FUEL FILTER	1	85.571.575
8	FUEL FILTER (ONLY)	1	



PARTS BREAKDOWN INVERTER GENERATOR


MODEL:BE3500IP

FLYWHEEL/IMPELLER/STARTER PULLEY/IGNITION COIL



REF #	DESCRIPTION	QTY	BE PART #
7	IGNITION COIL TRIGGER	1	85.571.703
9	IGNITION COIL	1	

AIR CLEANER




REF #	DESCRIPTION	QTY	BE PART #
1	AIR CLEANER GASKET	1	85.571.702
2	NUT	2	
3	AIR CLEANER ASSEMBLY	1	
4	AIR CLEANER ELEMENT	1	



PARTS BREAKDOWN INVERTER GENERATOR


MODEL:BE3500IP

MUFFLER



REF #	DESCRIPTION	QTY	BE PART #
1	MUFFLER ASSEMBLY	1	85.571.737
9	BOLT	2	
10	NUT	2	
11	EXHAUST OUTLET GASKET	1	
11	EXHAUST OUTLET GASKET(ONLY)	1	85.571.769

FUEL TANK




REF #	DESCRIPTION	QTY	BE PART #
1	FUEL TANK	1	85.571.738
2	BOLT	4	85.571.739
3	FLAT WASHER	4	
4	RUBBER SLEEVE	4	
5	BUSHING	4	
6	FUEL VALVE	1	85.571.740
7	FUEL STRAINER	1	85.571.710
8	FUEL CAP	1	
9	FUEL GAUGE	1	85.571.711



PARTS BREAKDOWN INVERTER GENERATOR


MODEL:BE3500IP

ENGINE FRAME



REF #	DESCRIPTION	QTY	BE PART #
1	FRAME ASSEMBLY	1	85.571.741
10	WHEEL SHAFT	1	85.571.704
11	WHEEL	1	
12	SLEEVE DUST COVER	1	
13	CABLE SLEEVE	1	

HANDLE




REF #	DESCRIPTION	QTY	BE PART #
1	HANDLE TUBE ASSEMBLY	1	85.571.712
2	SPRING WASHER	2	
3	BOLT	2	
4	RUBBER BLOCK	4	



PARTS BREAKDOWN INVERTER GENERATOR

MODEL:BE3500IP

CONTROL PANEL




REF #	DESCRIPTION	QTY	BE PART #
1	CONTROL PANEL ASSEMBLY	1	85.571.707
3	PANEL SEAT	1	85.571.743
19	FUEL TUBE	1	85.571.744
20	COLLAR	1	
21	COLLAR	1	
22	BREAKER	1	85.571.586
23	AUTO IDLE SWITCH	1	85.571.746
24	IGNITOR	1	85.571.747
25	120V TWISTLOCK SOCKET	1	85.571.748
26	120V DUPLEX SOCKET	1	85.571.592
27	BREAKER, 27 AMP	1	85.571.750
28	BREAKER, 20AMP	1	85.571.751
29	RED PARALELL SOCKET	1	85.571.589
30	BLACK PARALELL SOCKET	1	85.571.590
31	GROUNDING TERMINAL	1	85.571.654
32	12V SOCKET	1	85.571.652
33	USB SOCKET	1	85.571.653
34	BREAKER	1	85.571.593
35	BRIDGE RECTIFIER	1	85.571.049



PARTS BREAKDOWN INVERTER GENERATOR

MODEL:BE3500IP

INVERTER COVER




REF #	DESCRIPTION	QTY	BE PART #
1	LEFT SIDE SHELL	1	85.571.615
4	GREY COLORED DOOR, LEFT SIDE	1	85.571.614
8	RIGHT SIDE SHELL (RECOIL SIDE)	1	85.571.617
9	GREY COLORED DOOR, RECOIL SIDE	1	85.571.616
12	TOP SPILL GUARD	1	85.571.761
20	SPARK PLUG REPAIR KNOB	1	85.571.762
21	SPRING CLIP	1	85.571.763



PARTS BREAKDOWN INVERTER GENERATOR


MODEL:BE3500IP

INVERTER BASE



REF #	DESCRIPTION	QTY	BE PART #
1	BASE PLATE	1	85.571.764
2	FRAME SEAT	2	85.571.765
3	BOLT	2	
9	SHOCK ABSORBER	2	85.571.766
10	SHOCK ABSORBER	2	
14	INVERTER ASSEMBLY	1	85.571.705
23	CARBON CANISTER	1	85.571.706

MUFFLER COVER



REF #	DESCRIPTION	QTY	BE PART #
5	MUFFLER COVER PANEL	1	85.571.768



PARTS BREAKDOWN INVERTER GENERATOR

MODEL:BE3500IP

ALLIGATOR CLIPS ACCESSORY



REF #	DESCRIPTION	QTY	BE PART #
1	12v Alligator Clip Set	1	85.571.000

BE

POWER EQUIPMENT

If you need technical assistance call:

1-866-850-6662

(8:00am - 4:30pm PST, Mon - Fri)